

## **VR7888**

Fluid Management Solution



There are two models of the Veeder-Root mechanical ticket printer, a Accumulative and a Zero Start.

The Accumulative Printer, before delivery prints the total remaining from the previous delivery. After delivery, the total accumulated at that point is printed. The amount just delivered is found by subtracting the previous total from the accumulated total

The Zero Start Printer model first prints zeros. The total printed after delivery is the actual amount of the transaction. No arithmetic is needed.

